

<b>2420 GEN II L-SEALERS</b>	
<b>COMPONENTS ON SEAL ARM ASSEMBLY</b>	<b>part #</b>
SEAL WIRE SINGLE	10-41690-23
BEARINGS, SEAL HEAD PIVOT BEARINGS	560-70-06
BOLTS, ADJUSTERS FOR MAG/SEAL WIRE MICRO SWITCHES	527-65-40-01
CAM	10-16048
CAM HANDLE	10-16049
GROUND STRAP (copper " C" plate at corner)	10-41686
GROUNDING BLOCK (right side anchor point of front seal wire)	10-36224
INSULATOR, PLASTIC FOR BRASS POST	557-20-64
MOUNTING SHAFT FOT TENSIONER CAM & SPRING	10-16129
NUT, BRASS (for anchor screw and post)	545-24-20-30
POST, BRASS (front anchor point on side seal wire)	553-44-02
RTV CEMENT (attaches transite strip)	573-10-02-01
SCREW, (attaches front seal wire at corner)	521-12-02-01
SCREW, BRASS (seal wire anchor bolt mounted in tensioner)	524-24-71-30
SEAL WIRE CONNECTOR KIT	10-16201
SPRING, (for tensioner assembly)	562-70-17
STUD FOR SPRING MOUNTING	10-16145
TENSIONER ASSY, W/CAM, STUDS, SPRINGS MOUNT-SIDE	10-41212
TENSIONER ASSY, W/CAM, STUDS, SPRINGS, MOUNT -FRONT	10-41211
THREADED ROD, HOLDS MICROSWITCH ADJUST BOLTS EM	10-40130
THREADED ROD, HOLDS MICROSWITCH ADJUST BOLTS GSM/MTB	10-36227-02
THUMB NUT (black plastic attaches seal wires)	568-03-03
TRANSITE INSULATOR 40" LENGTHS (under seal wires)	10-16041-18
WASHER, BRASS (under thumb nut & screw above)	548-24-19
WASHERS, PLASTIC (brass post mounting insulators)	548-24-13
<b>FILM HOLDDOWNS</b>	<b>part #</b>
FILM HOLDDOWN, COMPLETE FRONT	10-41104-17
FILM HOLDDOWN, COMPLETE SIDE	10-41104-03
SHOULDER BOLTS FOR HOLDDOWNS	10-16449
SPRING FOR HOLDDOWNS	562-72-47
<b>CLOSER (DOOR) ASSEMBLY/ COUNTER WEIGHT</b>	<b>part #</b>
CLOSER ASSEMBLY GSMSL	10-40168
CLOSER ASSEMBLY MTB	10-40168
COUNTER WEIGHT MTB	10-40126-01
COUNTER WEIGHT SUPPORT ROD, (HOOKS)	10-40094
<b>SEAL PAD ASSEMBLY COMPONENTS</b>	<b>part #</b>
SEAL BED ASSEMBLY	10-54188
SEAL BED RETAINING COMPONENTS MACHINE SCREW	521-64-71-02
NYLOCK NUT	546-57-08
WASHER	548-24-25
SEAL BED SPRING L/F & R/R (lighter gauge)	562-72-64
SEAL BED SPRING both in corner (heavy gauge)	562-72-15
SEAL PAD 1" FOAM 36 " LENGTH	10-50588-05
SEAL PAD 1" FOAM 45 " LENGTH	10-50588-06

TEFLON SLEEVE MATERIAL 12" X 9 YARDS	573-56-64
TEFLON TAPE 2 1/2" 9 YARD ROLL	573-56-68
TEFLON TAPE 3/4" 10 YARD ROLL	573-56-69
TEFLON TAPE 3/4" 36 YARD ROLL	573-56-17-01
<b>MAGNET ASSEMBLY COMPONENTS</b>	
	part #
BOLT, (mounts spring and plate to bracket)	531-66-73-01
TREMINAL STRIP 4 PIN FOR RECTIFIER	600-50-06
BRACKET, CONTACT PLATE MOUNTING	10-50835
BRACKET, MAGNET HOLDER	10-50833
CONTACT PLATE (mounted to seal head)	10-50834
MAGNET	640-40-06
NUT, NYLOCK	546-57-34
RECTIFIER ASSEMBLY	10-40082
SPRING, (on contact plate)	562-77-66
WASHER	548-50-05
<b>GSMSL MODEL PRODUCT TRAY COMPONENTS</b>	
	part #
<b>FOR MODELS WITHOUT CONVEYOR</b>	
BASE, CHANNEL ASSMY	10-54210
LOADING TABLE	10-54213
LOADING TRAY HEIGHT ADJUSTER	10-54216
SPRING, TABLE HEIGHT ASSIST	10-54211
<b>CONVEYOR ASSEMBLY COMPONENTS MB MODELS</b>	
	part #
ADJUSTER BOLT FOR TENSIONER ASSY	527-65-40-01
ANCHOR NUT FOR ADJUSTER	10-36181
BELT, CONVEYOR W/LACING & CONNECTOR ROD	10-36230
BELT, TIMING	562-32-01
BRUSHES- FOR CONVEYOR MOTOR	640-45-11
CRANK HANDLE	10-16591-02
DRIVE ROLLER	10-36460-01
DRIVE ROLLER BEARING	560-15-09
DRIVE ROLLER SPROCKET	562-22-07
IDLER ROLLER	10-36459-01
LAG TAPE FOR ROLLER	573-56-36
LIFT ROD, (on scissor jack replace w/lift screw)	10-36290-02
LIFT SCREW (threaded rod for cank handle)	10-41263
LIFT SCREW BUSHING, BRASS	10-36229
LIFT SCREW, COLLAR	557-07-09
MOTOR	615-40-11
MOTOR MOUNTING BRACKET	10-54176
MOTOR SPROCKET	562-22-06
<b>ELECTRICAL COMPONENTS</b>	
	part #
BRUSHES, MOTOR	640-45-11
CAPACITOR, MAGNET	632-21-52-06
CIRCUIT BREAKER, CONVEYOR	610-70-03
CIRCUIT BREAKER, MAIN POWER	610-70-10
CONTROLLER, BELT SPEED	10-54342

<b>CORD, MAIN POWER</b>	<b>10-40172-20</b>
<b>FUSE 2AMP FAST ACTING</b>	<b>600-62-34</b>
<b>FUSE 15AMP FAST ACTING</b>	<b>600-62-38</b>
<b>FUSE HOLDER ASSEMBLY</b>	<b>10-21634</b>
<b>LIGHT, INDICATOR (220 VOLT)</b>	<b>625-60-30</b>
<b>MAGNET (220 VOLT)</b>	<b>640-40-06</b>
<b>MOTOR, CONVEYOR</b>	<b>640-40-11</b>
<b>ON/ OFF SWITCH (TOGGLE)</b>	<b>610-14-09</b>
<b>RECTIFIER, MAGNETS</b>	<b>635-70-29</b>
<b>RELAY CONTACTOR</b>	<b>610-50-04</b>
<b>SWITCH, SEAL,MAGNET,CONVEYO (MICROSWITCH)</b>	<b>610-18-22</b>
<b>TERMINAL JUMPER</b>	<b>600-54-01</b>
<b>TERMINAL STRIP 16 PIN</b>	<b>600-54-01</b>
<b>TERMINAL STRIP 9 PIN</b>	<b>600-50-10</b>
<b>TIMER KNOB (round)</b>	<b>568-03-23</b>
<b>TIMER, CONVEYOR AND MAGNETS (EM UP DWELL)</b>	<b>10-54180-91</b>
<b>TRANSFORMER, (HOLEBURNER)</b>	<b>640-10-35</b>
<b>TRANSFORMER, (SEAL WIRES)</b>	<b>640-10-29</b>
<b>SEAL WIRE TEMP &amp; BALANCE COMPONENTS</b>	<b>part #</b>
<b>BALAST WIRE TEMP EQUALIZER JUMPER</b>	<b>NOT REQUIRED</b>
<b>CONTACT SWITCH, ADJUSTING DIAL ON FRONT PANEL</b>	<b>610-18-23</b>
<b>KNOB, (for contact switch)</b>	<b>568-30-02</b>
<b>MONITOR WIRE</b>	<b>10-16457</b>
<b>TEMP CONTROL ASSEMBLY " K TIMER" " MONITOR)</b>	<b>10-40014</b>
<b>FILM CRADLE/ SEPERATOR TRAY ASSEMBLY</b>	<b>part #</b>
<b>FILM CRADLE ASSEMBLY</b>	<b>10-41407</b>
<b>BRACKET, (for film opening rod)</b>	<b>10-50552</b>
<b>BRAKE</b>	<b>10-50554</b>
<b>COLLAR , (for roller installation)</b>	<b>557-07-09</b>
<b>COLLAR FILM POSITIONING</b>	<b>10-36466</b>
<b>CRADLE TIE SUPPORT</b>	<b>10-16615-03</b>
<b>FILM OPENING ROD</b>	<b>10-50553-02</b>
<b>FRONT PLATE, ROLLER MOUNT</b>	<b>10-54193</b>
<b>REAR PLATE</b>	<b>10-36390-01</b>
<b>ROLLER</b>	<b>10-36458-01</b>
<b>ROLLER MOUNTING BRACKET</b>	<b>10-16441</b>
<b>SEPERATOR TRAY STAINLESS STEEL</b>	<b>10-54231-21</b>
<b>THUMBKNOB, (black plastic for opening rod position)</b>	<b>568-20-05</b>
<b>SHELF</b>	<b>10-54171-01</b>