



Product Data Sheet

# Rubber Regenerator

Rubber Regenerator Conditioner

### Product Information

**Rubber Regenerator** is a rejuvenating and deglazing formula that effectively removes ink, varnish and gum glaze conditioning rubber surfaces. This formula restores rubber plasticizers reconditioning rubber surfaces to a smooth velvety finish. Rubber Regenerator extends blanket and roller life when used regularly as part of a preventive maintenance program.

### Features & Benefits

- Deglazes and rejuvenates
- Eliminates ink, varnish and gum deposits
- Restores rubber plasticizer

### Directions:

**Rollers** - Apply small amount of Rubber Regenerator over distributor roller. Run press for 3 - 4 minutes. Afterward, engage wash-up blade and rinse rollers with a water miscible blanket and roller wash.

**Blankets** - Wipe Rubber Regenerator over entire blanket surface. Allow to penetrate for 2 - 3 minutes. Afterwards, wash blanket with a water miscible blanket wash.

### Specifications

Color.....Clear  
 Odor.....Solvent  
 VOC.....4.5 lb. / gal.

### HMIS

Health.....2  
 Fire.....3  
 Reactivity.....0  
 Personal Protection.....B

### Información de Producto

**Rubber Regenerator** es una formula rejuvenecedora que efectivamente remueve todo residuo de tinta y barniz de los rodillos de caucho. Esta formula restaura los plastificantes de la goma acondicionando la superficie a un terminado sedoso. Rubber Regenerator extiende la vida de los rodillos y mantillas cuando su uso es incorporado en un programa de manutención preventiva.

### Beneficios y Características

- Rejuvenecedor y descristalizador
- Elimina todo residuo de tinta y barniz
- Restaura los plastificantes

### Direcciones de Uso

**Rodillos** - Aplique pequeña cantidad de Rubber Regenerator sobre el rodillo distribuidor. Corra la prensa por 3 - 4 minutos. Después, crie la cuchilla y enjuague la batería de rodillos con un lavador de rodillos y mantilla miscible al agua.

**Mantillas** - Aplique Rubber Regenerator sobre la superficie de la mantilla. Mantenga en la mantilla de 2 - 3 minutos. Después, enjuague la mantilla con un lavador de mantillas miscible al agua.

### Especificaciones

Color.....Transparente  
 Olor.....Solvente  
 COV.....4.5 lb. / gal.

### HMIS

Salud.....2  
 Inflamabilidad.....3  
 Reactividad.....0  
 Protección Personal.....B

